

Intercom & entry · face terminal

Space Pad BIO

Your face is your key.

Models: **SP-B5** (5") · **Space Pad BIO 8"**



Illustrative image, screen switched off.

Real-life example

An office of 120 people. An employee walks up to the door and the terminal recognises him in a split second, with nothing to touch. The entry goes straight into time and attendance.

The cleaning crew has cards that only work at selected hours. Anyone who prefers not to use face recognition can enter with a card or a code.

Key functions

Many ways in

Face, NFC/IC card, QR code, PIN code and fingerprint; QR and fingerprint depend on the version.

Attendance and visitors

Every entry and exit is logged for attendance, and visitors and service crews get access for set hours.

Choose your connection

Network cable, Wi-Fi or cellular (option). User management and remote opening from the SpaceEngine platform.

Specifications

Models	SP-B5 (5" screen), Space Pad BIO 8" (8" screen)
Entry methods	face, NFC/IC card, QR code and fingerprint (depending on version), PIN code
Built-in access method	Palm and vein scan
Optional, on order	Bluetooth 6.0 (BLE) module: automatic opening with a BLE beacon and direct local connection to the app
Camera	2 MP (1920 × 1080), dual-lens with infrared
Face recognition	≤ 0.2 s (manufacturer declaration)
Users	up to 30,000 locally (manufacturer declaration)
Connectivity	RJ-45, Wi-Fi, Bluetooth, optional cellular
Power	12 V DC
Operating temperature	−20 ... +55 °C
Mounting	surface
Dimensions 8"	256 × 124 × 21 mm
Colour	black
Warranty	12 months. We tailor warranty periods to the client's needs and tender requirements.

Works with the SPACE system

The terminal connects to the SpaceEngine platform: users, permissions and remote opening live in the same system as SPACE locks. There is always an alternative to the face: a card or a code.

Ordering

- We will prepare a quote for your project.
- Device selection, network design, installation and commissioning by SPACE or an authorised installer.
- Before go-live we set unique passwords and the site configuration.

Contact and orders

+48 533 909 533

support@spacebms.com · www.spacebms.com

Space BMS sp. z o.o., ul. Zbożowa 3/6, 30-002 Kraków